CONFIGURATION ALEXA WITH TFT WIFI

Connection:

- To connect the devices to the home assistant, they have to be connected previsouly to a FENIX TFT Wi-Fi application account.
- Enter in Alexa App and click “More”
- Click on “Skills and Games”
- Search for “FENIX TFT WiFi”
- Allow the use of the skill
- Confirm connection data to the FENIX TFT WiFi account







Devices:

- Once connected, Alexa can detect all the devices connected to the Fenix TFT Wi-Fi account.
- You can then Access to them and check the status from the menu Devices/Thermostats



Voice control:

- You can then control the current room temperature, set up a new temperature or/and switching the different modes of the thermostats.

    - You can know the current temperature, asking for instance :
      « Alexa, what is the temperature in the bathroom?»
    - Or change the mode, saying :
      « Alexa, switch on the heating in the living room»
    - Or change the setup temperature :
      « Alexa, set the kitchen temperature to 21 degrees»